



OPERATION AND MAINTENANCE INSTRUCTIONS

AVK WEDGE GATE VALVES FOR WATER AND WASTE WATER

21/00, 21/01, 21/60

1. INTRODUCTION

Operation and Maintenance instructions for the series 21/00, 21/01 and the 21/60 wedge gate valves.



2. HEALTH AND SAFETY PRECAUTIONS

The valve is designed for underground use with minimum maintenance and requires no lubrication. In the event of a spares replacement becoming necessary the recommended procedure is as follows:- All of the following procedures must be carried out with due regard to relevant Road Traffic Act Guidelines, Health and Safety and COSHH directives.

SAFETY NOTE: Please take care when lifting either valves or components thereof, that health and safety guidelines are observed.

SAFETY NOTE: The valves now accommodate lifting bars for the safe handling of valves. These lifting bars are rated to the weight of the bare valve and stem cap (where fitted) only and should not be utilised if the valve is fitted with pipe, mechanical pipe joints, gearboxes, actuators or any other external fitment. AVK will not accept any responsibility for loss or damage if the lifting bars are not used in strict accordance with this guidance.

NOTE: The valves are NOT designed for “end of line” services. In the event of a valve being mounted on the end of a pipeline, we strongly advise the use of a blanking flange or plug.

NOTE: Resilient seated isolating (gate) valves designed for waterworks purposes may have a small air gap under the wedge bottom if being closed in dry conditions, using relatively low closing torque with the valve inadequately restrained. This is because the friction between the wedge rubber and the coated valve body seats is higher in dry conditions. The air gap is designed to allow for full compression of the rubber on the wedge against all sealing surfaces. Full compression takes place when the rubber wedge is lubricated by the pipeline medium thus allowing the valve to be fully closed.

NOTE: It is recommended that applications in a corrosive atmosphere or sited in exposed locations or in proximity to sea water or spray, use a stainless steel stem 1.4404 (316) and all exposed fasteners are in A4 stainless steel. A class A coating (300 microns inside and out) is also recommended.

NOTE: Air Venting: whenever a valve or pipeline is being filled it should be done slowly. It is also vitally important to ensure that all air is vented, preferably by using air release valves particularly at the highest point in the pipeline. These will also assist when emptying the line.

AVK WEDGE GATE VALVES FOR WATER AND WASTE WATER

21/00, 21/01, 21/60

3. REPLACEMENT OF STEM SEAL

This can be carried out with valve under pressure in the pipeline, but take care over step 'a' to ensure a seal is formed between wedge and bonnet.

- a. Fully open valve to ensure it is back-seated.
- b. In the case of a stem cap being fitted carefully prise out plastic insert (20). Remove stem cap bolt (19) and stem cap (18).
- c. Remove 2 hexagon headed bolts (16) on top of gland flange (13).
- d. Gland flange (13) can now be lifted clear of stem (5) allowing access to the stem sealing arrangement. Lift clear of stem and replace the 2 'O' Rings (15) and it is recommended to lubricate the 'O' rings using a Water Regulations approved grease e.g. Rocol, Aqua-Sil. Refit bushing (14) on stem taking care not to nip or tear the new 'O' Rings.
- e. Refit gland flange (13) with a new gland flange 'O' Ring (12) and tighten the 2 hexagon headed bolts (16) using a torque wrench set at 100 NM to 110 NM. If the wiper ring (17) is damaged, a complete new gland flange must be fitted.
- f. Refit stem cap assembly i.e.:- (18) (19) (20).
- g. Close wedge by a few turns and check the integrity of the new seal arrangement.

4. REPLACEMENT OF WEDGE

- a. Isolate valve and ensure there is no pressure in the pipeline.
- b. Adjust handwheel or stem cap to put the wedge into a slightly open position.
- c. Remove hot melt / screw cover (9) to expose bonnet bolts (6) then remove bolts.
- d. Lift the entire bonnet assembly (8) and wedge (3) clear of valve body (1).
- e. Unscrew wedge (3) from the stem (5).
- f. Fit new wedge by reversing step 'e', take care that the wedge is in a mid-position on the stem so that when refitting it will be clear of the base of the body.
- g. Replace bonnet gasket (7). It is suggested that the bonnet bolts (6) are inserted into the bonnet holes first and then the gasket (7) is fitted over them. The whole bonnet assembly can now be refitted onto the body (1).
- h. Tighten the bonnet bolts (6) following a diagonal sequence and using a torque wrench set at 25NM to 30 NM. Re-set the torque wrench at 40 NM to 50 NM and re-tighten the bolts following a circumferential sequence.
- i. Check integrity of seal by re-charging the main. Ensure all air is vented prior to fitting the valve.
- j. Should any leakage be found, tighten bonnet bolts (6) following the diagonal sequence as in h) with the torque wrench set at 70 NM to 80 NM.

AVK WEDGE GATE VALVES FOR WATER AND WASTE WATER

21/00, 21/01, 21/60

5. REPLACEMENT OF STEM SEAL 'O' RING (Item 10)

- a. Isolate valve and ensure there is no pressure in the pipeline.
- b. Turn stem (5) to put the wedge (3) into a slightly open position.
- c. In the case of a stem cap being fitted carefully prise out plastic insert (20). Remove stem cap bolt (19) and stem cap (18).
- d. Remove 2 hexagon bolts (16) on top of gland flange (13).
- e. The gland flange (13) can now be lifted clear of stem (5) allowing access to the stem seal arrangement.
- f. Fully close the valve in order to raise the stem (5) clear of the bonnet (8), ensuring that the two thrust collars (11) are retained for re-assembly.
- g. Remove stem seal 'O' ring (10) and replace with a new 'O' ring (10), grease the 'O' ring with a Water Regulations approved grease e.g. Rocol Aqua-Sil.
- h. Replace the two 'O' rings (15) and nylon bushing (14) in the glandflange (13). Grease internally using the approved grease. Grease thrust collar grooves in stem (5). Screw stem (5) back into wedge (3) whilst fitting thrust collars (11) ensuring they seat fully inside recess in bonnet (8).
- i. Refit gland flange (13) with a new gland flange 'O' Ring (12) and tighten the 2 hexagon bolts (16) using a torque wrench set at 100 NM to 110 NM.
- j. Refit stem cap (18), bolt (19) and insert (20).
- k. Close wedge by a few turns and check the integrity of the new seal arrangement.
- l. To check the integrity of the new seal arrangement, it will be necessary to recharge the main slowly and open and close the wedge (3) a few times.

NOTE: It is vitally IMPORTANT to ensure all air is vented prior to fully charging the main.

Materials of construction

1	Body	Grey cast iron BS EN 1561 1997, EN-GJL-HB195 Grade 250
2	Casting	Ductile iron GGG-50 to DIN 1693
3	Rubber	EPDM
4	Stem nut	High tensile alloy Cz132, BS 2874
5	Stem	Stainless steel BS 970420 S 37
6	Bonnet bolts	Zinc coated carbon steel 8.8 (R)
7	Bonnet gasket	NBR rubber BS 2494 type 3
8	Bonnet	Grey cast iron BS EN 1561 1997, EN-GJL-HB195 Grade 250
9	Screw cover	Holt melt
10	O-ring stem seal	NBR-rubber, BS2494 type 3
11	Stem collar	High tensile alloy Cz 132, BS 2872
12	O-ring	NBR-rubber, BS 2494 type 3
13	Gland flange	Ductile iron to BS 2789, Grade 500-7
14	Bushing	Polyamid 6.6
15	O-ring	NBR-rubber, BS 2494 type 3
16	Gland bolts	Zinc covered steel 8.8 (R)
17	Wiper ring	NBR-rubber, BS 2494 type 3
18	Stem cap	Ductile iron to BS 2789, Grade 500-7
19	Stem cap bolt	Stainless steel BS 970 A2
20	Insert	PE plastic

